
ASSEMBLY INSTRUCTIONS



Elowen 28" Table Lamp

Item # MF3605

NOTICE:


Inspect item carefully before attempting to install. If there is any damage or obvious defect, do not install. Item may not be returned once it has been installed.

---

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Install harp **(C)** by squeezing together and inserting into the top of saddle **(D)**.
3. Remove finial **(A)** from harp **(C)**.
4. Remove shade **(B)** from packaging and install to harp **(C)** using finial **(A)**.
   NOTE: If shade has additional packaging, carefully cut from interior of shade to avoid damage.
5. Install light bulb into the socket.
6. Remove protective cover **(E)** from plug.
7. Plug into electrical outlet and test the fixture.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

UNPACKING NOTICE



Elowen 28” Table Lamp

Item # MF3605

NOTICE:

Please follow instructions below to avoid possible damages caused by improper removal.

---

1. Open box and remove top layer of packaging.
2. Evenly lift fixture in areas indicated by arrows until clear of box as show in digram.

   NOTE: Remove slowly to avoid damages.