
ASSEMBLY INSTRUCTIONS



Triple Swing Arm Floor Lamp

Item # S1200

NOTICE:

Inspect item carefully before attempting to install. If there is any damage or obvious defect, do not install. Item may not be returned once it has been installed.

---

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Thread lamp **(F)** to rod **(L)**.
3. Thread rod **(G)** to base **(H)**.
4. Install harp **(C)** by squeezing together and inserting into the top of saddle **(D)**.
5. Remove finial **(A)** from harp **(C)**.
6. Remove shade **(B)** from packaging and install to harp **(C)** using finial **(A)**.
   NOTE: If shade has additional packaging, carefully cut from interior of shade to avoid damage.
7. Install light bulb into the socket.
8. Loosen adjustment knob **(E)** to adjust rod **(L)** to desired height, then tighten adjustment knob **(E)**.
   NOTE: Help feed electrical cord in or out of lamp for smoother adjustment.
9. Adjust arms **(K)** to desired angle.
10. Remove protective cover **(I)** from plug **(J)**.
11. Plug into electrical outlet and test the fixture.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.